



Smartphones, TV remote controls, and other items you use on a daily basis are often contaminated with dangerous viruses and germs. A Mental Floss article titled Infographic: the Dirtiest Surfaces in Hotel Rooms discusses a study on bacteria levels in hotel rooms. The study found that TV remote controls are often highly contaminated with numerous dangerous bacteria.

Cleanintuv is an ideal way to clean a TV remote control, cell phone or almost any item that will fit in its large interior...in less than 1 minute.

Antimicrobial Test Laboratories conducted a study on the efficacy of an earlier version of the cleanintuy. The results showed a reduction of more than 99.999% in Staphylococcus aureus and a reduction of more than 99.9% in C. difficile

- The interior dimensions are 19.69 cm by 8.89 cm.
- Uses the long lasting Philips TUV4T5 (G4T5) bulb
- Rated for 6,000 hours or 360,000 seconds
- That equates to 720,000 cycles!

cleanint sale agent




Charlia Pence charlia@diamondbusiness.net 806-373-4148 | 800-749-9025

MSRP \$ 249.95/ea USD

https://diamondbusiness.net/cleanituv




Quick Start Guide and Warranty Information



Unit Dimensions: 27.94 cm by 13.65cm Internal Dimensions: 19.69 cm by 8.89 cm Bulb Model: Philips G4T5 TUV 4W Operating and Electrical: Power (Nom) 4 W Lamp Current (Nom) 0.17 A Voltage (Nom) 29 V This device is not intended for cleaning medical devices.

Get to know your CleanintUV




Devices will not charge during a cleaning cycle. Do not attempt to clean a device that is plugged in and charging. Unplug the device before inserting into the CleanintUV.

On the back of the machine. – Use only CleanintUV included power cable or certified Cleanint accessories.

1. Plug in the CleanintUV with the included power cord to a nearby power outlet. Only use the included cable or Cleanint certified accessory.

2. Place the item to be cleaned into the CleanintUV. Sensor should begin the cleaning cycle. If the cycle does not begin, push the Power Cycle Button once to begin the cycle. The CleanintUV can be used to clean any inanimate object. Do not use on food.

The door will close and the LED lights will blink to show the cycle process.
Wait for the door to open completely. Retrieve and use your clean item.
If the LEDs continue to blink after the door is open, please visit cleanint.com/support. Cancel a cycle with long button press.



Additional Accessories Hook Tray Ring Insert back tab of accessory into the top opening of the guide and slide down to install. Remove by pulling up to the guide opening.

Disclaimers:

CleanintUV can be used to clean any inanimate, non-organic object that easily fits inside. Not to be used with food, animals or other organic material. Do not force the CleanintUV door to open or close. Do not force an item that does not easily fit into the CleanintUV. Cleanint, LLC is not responsible for damage, expense, injury or illness caused by the unauthorized use of, alterations to, improper connection of, and abuse or neglect of any and all Cleanint, LLC products.

Warranty: Please register your product at cleanint.com before submitting any warranty claim. Please follow the onscreen directions to complete your registration. Cleanint, LLC, the warrantor, will replace all products that have manufacturing defects free of charge for one(1) year after the date of purchase. This warranty does not cover damage, expense or injury caused by unauthorized repairs, alterations, improper connection, shipping, abuse, theft, accident or neglect. Also, this warranty does not cover collateral loss. Prior to returning a product for service you must obtain a return merchandise authorization number from Cleanint, LLC. Please contact us at 888.715.0464 to obtain the return authorization number. When returning your product, please include your name, USPS or Canadian address (no PO boxes), telephone number, RMA number and a complete description of the problem on all enclosed correspondence. When possible, pack product carefully in original carton. Customers are responsible for any shipping cost to Cleanint, LLC. Cleanint, LLC will pay the cost for shipping a replacement product to the customer but is not responsible for any damage that may occur as a result of that shipping.

For warranty service in the USA, send to:

Cleanint, LLC 3000 Joe Di
Maggio Blvd Ste $\mathbf{51}$ Round Rock, TX 78665 Phone 888.715.0464

For warranty service in Canada, please return the item to our Canadian distributor, CleanDevice Inc., PO Box 86071 MARDA LOOP, Calgary, AB T2T 6B7.

Please note that we (Cleanint, LLC) are the warrantor for Canadian purchases, but request that you return the product to CleanDevice Inc. locally in Canada (as a convenience to you).

Note: The provisions of this warranty are in addition to and not a modification of or subtraction from the statutory warranties and other rights and remedies contained in any applicable governmental act or regulation, including, but not limited to, the Consumer Products Warranties Act in Saskatchewan.

Trade Name: Cleanint Model #: CUV20-2018-CV Input: 5V ... 4A



This device complies with part 15 of the FCC Rules. Operation is subject to the following two criteria: (1) This device may not cause harnful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-005 (B) / NMB-005 (B)